



RC
ECT 5320




Note

RC
ECT 5320
Fly-jib




Note

RC
ECT 5320
EVS




Note

RC
ECT 5320
EVS
Fly-jib




Note

RC
ECT 5320
CIO 5374




Note

RC
ECT 5320
CIO 5374
Fly-jib




Note

RC
ECT 5320
EVS
CIO 5374



Note

RC
ECT 5320
EVS
CIO 5374
Fly-jib



NOTE!

Cable 3 from RCL to ECT5320 MUST be connectet this way. Applies to all the ECT5320 on this page.

DK:
Kabel 3 fra RCL til ECT5320 SKAL forbindes på denne måde. Det gælder alle ECT5320 på denne side.

2			
K131	GY	Supply -	K141
K232	PK	Supply +	K242
K333	YE	Ignition	K343
K434	BN	CAN Low	K444
K535	WH	CAN High	K545
K232	GN	Stop	K646
K737	BU	Stop	K747

Revision		
Nr.	Date	Sign.
A	28.07.2008	BWK
B	10.05.2010	BWK

Product	
RCL 5300	
Part	
Termination, RC400, ECT5320	
 Højbjerg Maskinfabrik a/s Oddervej 200 - DK-8270 Højbjerg	

Date	28.07.2008	Drawing size
Sign.	BWK	
		A3
Replacing		
Drawing nr.		
70 20 393		
Rep. by		