


The cables 83L and 83R connects to the sensor for extension boom out in the opposite side of where they are connected.



Date	02.02.2017	Drawing size
Sign.	BWK	A4
Replacing		
Drawing nr.		
70 21 309 01		
Rep. by		