


1. Add feature EVS
Remember to do
"Factory Calibration"

2. Configure Output Config:
 - a. Dout 1: **EVS HDL 1**
 - b. Dout 2: **EVS HDL 2**

- ### 3. Configure Valve Sensing:
- a. Slew: **Sensor**
 - b. Boom: **Sensor**
 - c. Jib: **Sensor**
 - d. Ext: **Sensor**

4. Configure Valve Input:
 - a. Set up inputs for **Slew spool sensor**
 - b. Set up inputs for **Boom spool sensor**
 - c. Set up inputs for **Jib spool sensor**
 - d. Set up inputs for **Extension spool sensor**



Revision			Product		Date		Drawing size	
Nr.	Date	Sign.	RCL 5300		12.10.2015		A3	
A	12.10.2015	BWK			BWK			
			Part		Replacing			
					Drawing nr.			
			 Højbjerg Maskinfabrik A/S Oddervej 200 - DK-8270 Højbjerg		70 21 432 02			
					Rep. by			