

Notes:

- 1. Add feature EVS
Remember to do
"Factory Calibration"
- 2. Configure Output Config:
 - a. Dout 1: **EVS HDL 1**
 - b. Dout 2: **EVS HDL 2**
- 3. Configure Valve Sensing:
 - a. Slew: **Sensor**
 - b. Boom: **Sensor**
 - c. Jib: **Sensor**
 - d. Ext: **Sensor**
- 4. Configure Valve Input:
 - a. Set up inputs for **Slew spool sensor**
 - b. Set up inputs for **Boom spool sensor**
 - c. Set up inputs for **Jib spool sensor**
 - d. Set up inputs for **Extension spool sensor**

